

VIDEO PRINTING PAPER

SONY

BLACK & WHITE PRINTERS

PRINTER TYPE	MANUFACTURER'S PAPER REFERENCE	ORIGIN	RE-ORDER NUMBER	TYPE	MEDIUM	WIDTH (mm)	LENGHT (M)	BOX
UP102-UB	UPP105/SNY	CROWN	2013903	ROLL	PAPER	105	20	4
UP-104	UPP110/SNY	CROWN	2000344	ROLL	PAPER	110	20	4
UP850 (D) 860-CE, 890-CE	UPP110S	SONY	2019085	ROLL	STANDARD FILM	110	20	12
	UPP110HD	SONY	2019086	ROLL	HIGH DENSITY FILM	110	20	5
	UPP110HA	SONY	2021977	ROLL	SUPERIOR DENSITY FILM	110	18	5
UP910, 930	UPP216SE	SONY	2019084	ROLL	STANDARD	216	25	5
	UPP216HD	SONY	2019087	ROLL	HIGH DENSITY	216	25	5

VIDEO PRINTING PAPER

SONY CONTINUED

COLOUR PRINTERS

PRINTER TYPE	MANUFACTURER'S PAPER REFERENCE	ORIGIN	RE-ORDER NUMBER	TYPE	MEDIUM	WIDTH (mm)	LENGHT (M)	BOX
UP3000 UP3030P	UPC301CP	SONY	2019159	SHEETS	STANDARD COLOUR	100	140	80 + Ribbon
	UPC3020	SONY	2019357	SHEETS	BLACK/WHITE	100	140	40+ Ribbon
UP5200 UP5250MDP	UPC5010A	SONY	2020785	SHEETS	COLOUR GLOSSY	148	210	100+ Ribbon
	UPC5010P	SONY	2019137	SHEETS	STANDARD COLOUR	148	210	100+ Ribbon
	UPC5020	SONY	2019358	SHEETS	BLACK/WHITE	148	210	100 + Ribbon
	UPC5030	SONY	2019359	SHEETS	TRANSPARANCIES	148	210	50+ Ribbon

VIDEO PRINTING PAPER

SONY CONTINUED

COLOUR PRINTERS								
PRINTER TYPE	MANUFACTURER'S PAPER REFERENCE	ORIGIN	RE-ORDER NUMBER	TYPE	MEDIUM	WIDTH (mm)	LENGHT (M)	BOX
UP7000P UPD7000E	UPC7010P	SONY	2019360	SHEETS	STANDARD COLOUR	210	297	100+ Ribbon
	UPC7020	SONY	2019361	SHEETS	BLACK/WHITE	210	297	100+ Ribbon
	UPC7030	SONY	2019362	SHEETS	TRANSPARANCIES	210	297	100+ Ribbon
UP2200P	VPM-30-STA	SONY	2019363	SHEETS	STANDARD COLOUR	100	140	30+ Ribbon
	VPM-90-STA	SONY	2019083	SHEETS	STANDARD COLOUR	100	140	90 + Ribbon
UP1200-EPM 1800-EPM	UPC1010	SONY	2019864	SHEETS	STANDARD COLOUR	100	140	100+ Ribbon
UP1850-EPM D1500CNE	UPC1020	SONY	2019973	SHEETS	BLACK/WHITE	100	140	100 + Ribbon